
QUESTION 1

The wind load on a water tank outside Winnipeg is shown in the figure below. The <u>total weight</u> of the water and the tower is 1000 N (acting vertically downward on the y axis).

- a) Find the equivalent force-couple at the intersection of the x and y axis.
- b) Replace the force system by a single force and determine where the line of action of this force crosses the x and y axis.





QUESTION 2

The pole has a fixed support at A. A truss is supported by the pole by a pin support at C and a roller support at B. A winch is used to lift a small airplane that has a mass of 500 kg (use $g = 9.8 \text{ m/sec}^2$). The cable attached to the winch goes over a pulley that is attached to the truss at D. A 500 N load is also applied to the truss at H.

Determine:

- a) The reactions of the pulley on the truss at D,
- b) The reactions at the fixed support at A, and
- c) The force in each member of the truss and state whether it is in tension or compression. (Show all of your results on the figure provided.)







QUESTION 3

For the frame shown in the figure, determine:

- a) The tension in the support cable and the reaction at the pin support at A, and
- b) The force in members ACD and AB.





FROME Re-draw pin 5Fx = -825.8 + 427.6 + FB cos70° = 0 FB = +1164.3N FB = 1164.3" To onpinet A Check Pin at B check. 45° 2Fx=0 -1835,1 cos 200 +1835.1 cos 450 +1168 cos 45° - 1164.3 sin 20° = 0 0.54:0 V